


PIPE CENTRES

Vertical = radiator width + valves **Horizontal** = radiator width - 45mm



SINGLE Wall to front face = 61mm Wall to pipe centre = 20mm On the Single Horizontal, only straight valves can be used. DOUBLE Wall to front face = 105mm Wall to pipe centre = 61mm

