
# **TALLIS** Vertical

- Italian design & manufacture
- 50mm x 25mm Oval Tubes in Single & Double; 1 heights & 4 widths
- Standard White RAL 9016 delivered in 48-72 hours
- 25 RAL colours, 8 special finishes, up to 15 working days (page 11)

#### **Sizes and Prices**

Dimensions (mm)		Elements	Output ∆t 50°c		Product Code		
Height	Width		Watts	Btu's			
Vertical - Single							
1820	300	5	627	2139	TALL183005SV		
	420	7	878	2996	TALL184207SV		
	480	8	1004	3426	TALL184808SV 🔶		
	600	10	1255	4282	TALL186010SV		
Vertical - Double							
1820	300	10	950	3241	TALL183010DV		
	420	14	1331	4541	TALL184214DV		
	480	16	1521	5190	TALL184816DV		
	600	20	1901	6486	TALL186020DV		

#### **Pipe Centres and Technical Drawings**



hrs **10** YEAR








◆ TALLIS Single Vertical RAL 9016 1820mm x 480mm shown with WELLINGTON TRV's.

### Supplies4Heat

## Tallis Vertical Fitting Instructions

### Oval Tube Steel Radiator

Please read these instructions and terms and conditions carefully prior to installation. Failure to do so may invalidate the warranty.



### **Pipe Centres**


Pipe centres left to right = Pipe centres from wall = Depth from wall =

#### Single

width + valves 55mm 95mm

#### Double

width + valves 80mm - 90mm 120mm - 130mm



### 1. Unpack & Inspect

This product should have reached you in perfect condition. Please carefully unpack and inspect this radiator and all fittings. Your point of purchase must be notified of any shortages or damage within 28 days of delivery.

For further information please see terms and conditions at the bottom of the page

### 2. Contents

You should have:

- 1 Radiator
- 4 Wall Brackets
- 4 Wall Plugs
- 4 Screws 1 Airvent
- 1 x 5mm Hex key •
- 4 Wall Sleeves
- 1 x 8mm Hex key
- Screwdriver •

You will need:

Tape measure

Electric drill and bits

- Spirit level
- 1 Cover for Blanking Plug
- 1 Steel Diverter

#### Mark Bracket Positions 3\_

- 1. Mark bracket positions as per Fig. 3, measure the width (X) of the radiator less 120mm and the height (Y) of the radiator less 50mm to find your four fixing positions for the Wall sleeves.
- 2. The Wall Sleeve ("A" in Fig. 1) screws into the wall in the positions as described above.
- 3. Ensure diverter is in the correct position (see section 5).
- 4. Attach clamps B & C to collector between the 2nd and 3rd element from either side, do not overtighten (Fig. 1) this, to allow slight adjustment for inserting into wall sleeves.
- 5. Raise radiator and slot into Wall sleeves "A" and tighten (Fig. 4).

### 4. Fix Brackets

Using a suitable drill bit, screws and plugs, fix the brackets and level with a spirit level.

#### PLEASE NOTE:

It is essential that all brackets are level and square prior to hanging the radiator to ensure a vertical alignment for connecting the pipework.

### 5. Identifying diverter

Factory fitted steel diverters are used in all vertical models and can be identified by a sticker found on the underside of one collector. The radiator must be hung with the diverter at the bottom. If this sticker is missing simply look into both collectors, one will have a clear water way and one will have a deliberate blockage, this deliberate blockage is the diverter. Please note the diverter can not be removed

### 6. Hang & Commission

With the brackets sleeves firmly fixed and level, the radiator can be hung in position by inserting the brackets into the sleeves and securing with the grub scews provided.

When commissioning your radiator on an indirect/closed system we recommend using a suitable mixed metal inhibitor to protect against scale & corrosion.

#### Damage caused to systems not protected by a suitable inhibitor will not be covered by manufacturer's guarantee.

PLEASE NOTE: Systems using micro bore pipe work must have adequate pressure and flow rates for the number and style of radiators on the system.

### **Technical Specifications**

Materials	Steel
Connections	1/2" flow and return.
Test pressure	6 Bar
Testing authority	EN442
Maximum operating pressure	4 Bar
Maximum working temperature	95 °C
Packaging	Wrapped in polythene within cardboard box

### **Guarantees & Liabilities**

This product is guaranteed for 10 years. The guarantee is subject to the products being installed in accordance with British and or European standards as well as these fitting instructions. The guarantee in all cases are restricted to the free of charge replacement or repair of the failed product only. Our liability will under no circumstances extend beyond the repair or replacement of the product supplied by us. Claims for either labour in replacement or damage to property are not admissible. Any goods that are returned, in the event of a problem, will belong to us.

### **Terms & Conditions**

All products must be inspected once removed from the packaging and your point of purchase notified within 28 days of delivery of any scratches, blemishes or other damage. Your point of purchase will then agree appropriate action.

Imperfect radiators should therefore not be fitted and we will not accept responsibility for replacement of scratched or damaged radiators once they have been fitted. This includes any consequential loss or cost of fitting.

If we are not notified within 28 days of the date on the signed delivery note then it will be deemed that we have fully complied with our obligations and claims will not be considered.

Failure to comply with any of the above may invalidate any claims. We recommend that after you check the product on delivery that it is stored in its packaging to prevent damage prior to installation, we cannot accept responsibility for items damaged after delivery. For full details of our Terms and Conditions please visit

www.supplies4heat.co.uk or call us on 01342 306880.

#### www.supplies4heat.co.uk 01342 306880